

HD KEYCHAIN DVR W/SD CARD

Easy to Use

For Video Mode, press and hold the OFF/ON button for several seconds until the yellow light turns on. Press and hold the record button until the yellow light flashes three times. When the light turns off, it has started recording. To stop and save the video, press and hold the record button until the yellow light turns on again. To turn off, long press OFF/ON switch until the light turns off.

For Camera Mode, press and hold the OFF/ON button until yellow light turns on. Press the record button once and the yellow light will flash once and then take a photo. Press record button again to take another photo. Long press the OFF/ON button to turn off.

Time/Date Stamp Programming

First, create a new .TXT file named TAG and save it to the MicroSD (TF) card. Second, in the TAG.txt file, type the date and time in the following format: year, month, day, hour, minute and second. For example: 2011.04.1007:00:30. Save the file before exiting. The next time you begin recording, the time/date stamp will be recorded on the image.

LED Light Status:

Standby Status: Light on

Video Recording: Flashes three times, then turns off

Photo Mode: Light on, flashes once every time a photo is taken

Memory Full: Light will turn on

Low battery power: Flashing

Charging: Light is on, turns off when device battery is full and has finished charging

USB File Read / Write: Light flashing